LDBA **Description**

monocrom has developed a new concept of mounting high power diode bars. In the patented technology, exclusive from monocrom, the laser bars are clamped without soldering within two copper blocks which serve as electrodes as well as heat sinks.

The main features of our laser diodes are:

- Long LIFETIME. >20.000 hours. No mechanical stress. No maintenance required.
- Widest OPERATION MODE RANGE: from nanoseconds to CW.
- High BRIGHTNESS with minimum "SMILE" <0.5µm.
- High EFFICIENCY >50% and compact size.
- High ENERGY per laser pulse at LOW COST per Watt.
- Custom BEAM DELIVERY. Fiber-coupled, direct irradiation, collimated modules.
- Efficient COOLING. Conduction-cooled, Water cooled (tap water compatible). No problems of micro-channel degradation.
- Broad range of WAVELENGHTS, 635-2000 nm.
- Wide STORAGE temperature, -60°C to +85 °C.
- High FLEXIBILITY, for a wide range of applications.

If we do not have it, we can create it...

We are creating and manufacturing laser modules to our customers for more than fifteen years, thanks to the effort of a highly qualified, creative and motivated team. Our courage, creativity and dynamism make us different. We have demonstrated the applicability of new concepts in laser physics and tecnology, like our patented clamped high power diode laser, or our Q-Switched green SSL, capable of providing microseconds pulses and considered the most important development in Eye surgery from the last years. Our present challenge is to design an ultra lightweight and resistant green laser device for a space mission to MARS.

...and make it come true

Our in-house facilities, including a wide machinery park together with Optics Labs allow us to keep all the development and manufacturing processes inside, at monocrom.

We design, manufacture and guarantee all our products. We also offer to our customers an After-Sales service in order to make sure that we meet our customers' expectations.





info@monocrom.com TL. +34 938 149 450 FX. +34 938 143 767



Laser Diode Bar Assemblies





monocrom has developed a new concept of mounting high power diode lasers bars. In the patented technology, the laser bars are clamped without soldering within two copper blocks. This technology allows us to offer you the most reliable high power diode lasers.

Different solutions are available, from direct irradiation to fiber-coupled, from single bars to laser bar stacks of kW of power, from CW to nanosecond pulses, from visible to near-infrared, from conductive to water-cooled housing, and all adapted to our customers needs.

Laser Diode Bar Assemblies

OPEN PACKAGING

Reference:	LB-WWXYY-ZZMMM WW: Wavelength;	
	X: Cooling, P for passive, A for water; YY:number	
	or bars, from 01 to 10; ZZ:number of emitters;	
	MMM: operation mode, p, cw of qcw	
Laser bars:	20-90 % fill factor. 0,6 to 3mm resonator	
Wavelength:	635, 780, 810, 850, 880, 915, 940, 980, 1060 nm	
Optical power:	up to kWs	
Operation mode:	pulsed (nanoseconds-milliseconds), QCW, CW	
Housing:	standard, customised	
Cooling system:	Conductive, Active (tap water can be used)	
Beam delivery:	Non-collimated, FAC, FSAC collimated, fibre-delivery	















DIODE LASER PUMPING HEADS

Reference:	PH-PPP-MM PP: Peak power;
	MM: operation mode CW or QCW
Wavelength:	1064nm – Nd:YAG 3mm
	808nm- Diode Laser Pumping
Operation mode:	CW.
Optical power:	<100W @ CW / <300W @ CW
	<600W @ QCW / <1800W @ QCW
Housing:	A10, A15, S35, LLL.
Cooling system:	Water cooled, without micro-channels



WATER COOLED DIODE LASER HEADS

Reference:	LBS-WWXX-SXS (WW: Wavelength; XX: number	
	or bars, from 01 to 50; SXS: output spot size)	
Wavelength:	780, 810, 915, 940, 980 nm	
Optical power:	< 5000 W	
Operation mode:	QCW.	
Housing:	Customized	
Cooling system:	Water cooled, high cooling eff. without micro-channels	
Beam delivery:	Free or lens duct 6x6, 8x8, 10x10, 12x12.	
Main application:	skin treatment, 40 J/cm² from pulses of 20ms	



CONDUCTIVE DIODE LASER HEADS

LBS-WWPXX-ZZMMM-PPP-OO (WW: wavelength;
XX: number of bars; ZZ: number of emitters;
MM: operation mode; PPP: peak power; OO: optics)
780, 810, 915, 940, 980 nm
QCW.
< 5000 W
Customized
TEC
Direct irradiation, FAC-SAC, customized

FIBER-COUPLED DIODE LASER HEAD

Reference: LBS-WWPXX-ZZMMM-PPP-000		
	(WW: wavelength; XX: number of bars;	
	ZZ: number of emitters; MM: operation	mode;
	PPP: peak power; OO0: fiber output)	
Wavelength:	780, 810, 915, 940, 980 nm	
Operation mode:	CW, QCW	
Optical power:	< 500 W	
Housing:	Compact and light-weight	
Cooling system:	Water or conduction cooled	
Beam delivery:	100-600µm fibre	NEW
		no photo available

